



Rockwell

MANUFACTURING COMPANY

The Rockwell Building • Pittsburgh, Pa.

PM-402-04-651-5009

DATED 1M-6-1-69

ROCKWELL-DELTA "VS6"

15" VARIABLE SPEED DRILL PRESS (beginning with serial #139-3001)

SETTING UP

Your 15" Drill Press has been completely assembled and tested at the factory. All that is necessary for you to do is loosen the clamp nut (A) Fig. 6, on left hand side of head, that holds the head to the column, slide the head up until casting top is level with the top of the column and retighten clamp nut. Then loosen clamp nut (B) Fig. 6, move support collar (C) up against bottom of head, and tighten clamp nut. The table and all other machined or unpainted surfaces of the drill press are protected with a coating of rust preventive. This coating may be removed with a soft cloth moistened with kerosene (do not use acetone, gasoline or lacquer thinner for this purpose.) After cleaning, cover all unpainted surfaces with a light film of good machine oil.

MOTORS AND SPEEDS

A 1/2 hp, 1140 rpm or 3/4 hp, 1725 rpm motor is recommended for use on your drill press. With a 1140 rpm motor the spindle speeds will be 300 to 3100 rpm. With a 1725 rpm motor the spindle speeds will be 450 to 4700 rpm.

When selecting a motor from any other source, be certain that it has the above specifications and is a NEMA 56 frame motor. Also be sure it is protected against loss of lubricant when operated in a vertical position.

When assembled to the drill press, the motor should turn in a clockwise direction as viewed from the top.






Fig. 2

VARIABLE SPEED CONTROL

The pilot wheel (A) Fig. 2, for Variable Speed Drive, should not be turned except when the motor is running, to avoid putting unnecessary strain on the variable speed drive belt and variable speed drive pulley assembly. The pilot wheel is turned clockwise to make the drill press run faster, and counter-clockwise to slow it down.

While changing speeds the pointer (B) Fig. 2, will indicate the speed of the drill press.




Fig. 3

A drag plug or "dampener" is provided to restrict the free rotation of the pilot wheel. The drag plug is properly adjusted at the factory so that the drill press will hold a constant speed and will not change speeds even on long production runs, but still the pilot wheel can be turned manually to change speeds as desired. If it ever becomes necessary to change the adjustment, use a long Allen wrench and insert it down through the hole located in the top of the guard, as shown in Fig. 3. Turn the set screw (A) Fig. 3, clockwise to increase or counter-clockwise to decrease the "dampener" pressure on the pilot wheel.




Fig. 3-A

Similar drag plugs or "dampeners" are provided in the spindle pulley and motor pulley assemblies, and are adjusted at the factory. After long service, it may be desirable to increase the pressure on the drag plugs by tightening set screws (A) Fig. 3A for the spindle pulley, and (M) Fig. 8 for the motor pulley. This adjustment does not have to be made, unless normal wear has resulted in noisy operation of the pulleys.




Fig. 4

TABLE ADJUSTMENTS

To adjust the table up or down loosen the lock bolt (A) Fig. 4, on the table bracket. Hold the table while doing so.

To tilt the table to the right or left, loosen the pivot nut located under the table, remove the pin (B) and tilt the table to the required angle and tighten the pivot nut. To set the table vertical, accurately, move the table to a vertical position, insert the pin (B) through one of the side holes in the apron of the table proper, and into the hole in the table bracket, then tighten the pivot nut. To return the table to the horizontal position, loosen the pivot nut, withdraw the pin (B), set the table level, then reinser the pin through its holes and tighten the pivot nut.

The table has been designed with ledges, one on each side, to facilitate the clamping of work pieces. The table may also be tilted to any degree between horizontal and vertical positions. A scale (C) Fig. 4, is located at the rear of the table, and is graduated in degrees. When the table is tilted between horizontal and vertical positions, the pin (B) must be removed. The table can be tilted either right or left.

QUILL ADJUSTMENTS

The spindle is raised and lowered by the pilot wheel (A) Fig. 5. The quill can be locked at any desired point in its travel by tightening the quill lever (B) Fig. 5. This is an especially desirable feature for router and shaper work.

The adjusting screw (C) Fig. 5 and nut (D) are set at the factory to give the quill the proper sliding fit in the head casting. After long service play between quill and head casting can be removed without the need to replace these parts. The nut (D) Fig. 5 is loosened, adjustment is made with the screw (C), and the nut is again tightened to prevent the screw from turning. Hold the screw with a screwdriver when nut is tightened, and check by moving the quill up and down several times to be sure the quill does not bind. This adjustment should be made with the stop rod (E) Fig. 5 removed.




Fig. 5

DRILLING HOLES TO DEPTH

When drilling one or two holes to a predetermined depth, the calibrations on the face of the depth stop rod (E) Fig. 5, can be used.

When drilling a number of holes to a predetermined depth, or if a more exact setting is required, proceed as follows:

1. Raise the locking sleeve (F) Fig. 5, and turn the micro-nut (G) to the desired position on the stop rod (E).
2. Lower the locking sleeve (F) so it will engage micro-nut (G) Fig. 5. Lock sleeve in place with thumb screw if drill press head is mounted in other than vertical position. When the drill press is mounted with the chuck pointing up the locking sleeve (F) and micro-nut (G) Fig. 5, should be reversed on the stop rod (E).
3. When locking sleeve (F) is in place on the micro-nut (G) Fig. 5, the micro-nut can not be turned. When a change in depth is required, the locking sleeve (F) must be raised and while it is raised, turn the micro-nut (G) the necessary calibration marks. Each mark represents .002". Then lower the locking sleeve.

4. The use of the micro-set stop nut will maintain the same hole depth, no matter how many holes are to be drilled. However, we recommend that the hole depth be checked whenever a drill has to be sharpened or changed.




Fig. 6

ADJUSTING SPINDLE RETURN SPRING

For the purpose of automatically returning the spindle upward after the hole has been drilled, a clock spring is provided enclosed in the case (D) Fig. 6. This spring has been properly adjusted at the factory and should not be disturbed unless absolutely necessary. If at any time it is necessary to adjust it proceed as follows:

1. To increase the tension of the spring, turn the screw (E) Fig. 6, which is located underneath the head, clockwise. CAUTION: BE CAREFUL NOT TO BOTTOM RETURN SPRING WHILE TURNING SCREW (E) FIG. 6, CLOCKWISE, THERE SHOULD BE ENOUGH SLACK LEFT IN SPRING TO PERMIT LOWERING THE SPINDLE THE FULL AMOUNT OF TRAVEL.
2. To decrease tension of the spring, turn the screw (E) Fig. 6, counterclockwise.
3. The tension of the spring can be tested by pulling down the pilot wheel lever (F) Fig. 6, and testing to see if the quill will return to the up position. Be sure the quill locking lever (G) Fig. 6, is loose while testing. NOTE: Before determining if this adjustment is necessary, make sure the stop rod (E) Fig. 5, runs freely up and down and is not twisted in the slot or guide of the head casting.

HOW TO CHANGE SPINDLE ADAPTERS

One of the unique features of the Variable Speed 15" Drill Press is the ease with which various spindle adapters may be used.



Fig. 7

When removing either the chuck or the spindle adapters, we recommend the use of the Cat. No. 15-838 spanner wrench which is supplied with your drill press. Turn the locking collar of the adapter or chuck with the spanner wrench while keeping the spindle from turning by either holding V-belt or holding the chuck with the chuck key in one of the pilot holes in the nose of the chuck, as shown in Fig. 7.

When attaching adapters to the spindle, it is very important to wipe clean both the spindle taper and taper hole in adapter. Then place the adapter on the spindle and tighten the locking collar (A) Fig. 7. If in checking the spindle for accuracy, there should be a run out, we suggest that the adapter be removed and turned perhaps one quarter or one-half turn and replaced. This may reduce or eliminate the run out, it may also increase it, in which case, remove the adapter and turn it some more on the spindle.

INSTALLING MOTOR

1. When installing a Rockwell 6" Frame Motor, insert the key in the keyway of the motor shaft and place the pulley on the motor shaft until the edge of the pulley sleeve is against the shoulder of the motor shaft.

2. When installing a NEMA 56 Frame Motor, insert the key in the keyway of the motor shaft and place the pulley on the motor shaft, with the edge of the pulley sleeve $1/8"$ from the shoulder on the motor shaft.

3. If you are installing a NEMA 56 Frame Motor, it is necessary to remove the two upper motor mounting studs (A) Fig. 8, and reposition them in the holes (B) directly below.

4. Make sure the key is in place and tighten the two set screws (C) against the motor shaft.




Fig. 8

5. Place the motor on the four motor mounting studs (A) Fig. 8, and install belt.

6. Visually line up the motor shaft so that it is in parallel alignment with the spindle. If the motor must be tilted to the front or rear, it is necessary to loosen the four nuts (D) and move studs (A) in or out as desired until the motor shaft is parallel with the spindle. Then tighten the four nuts (D) Fig. 8.

7. After the motor shaft is in parallel alignment with the spindle, adjust the belt tension. The correct tension is obtained when the distance from the center of the spindle to the center of the motor shaft is approximately $15 \frac{1}{8}"$. This may be done by following Steps 8 and 9. When making this adjustment it is important that the motor is kept in parallel alignment with the spindle pulley.

8. If the motor must be moved further away from the spindle, back off each of the four nuts (D) and back off the four studs (A) an equal number of turns against the motor base plate.

9. If the motor must be moved forward turn in each of the four studs (A) an equal number of turns and tighten nuts (D) against the motor base plate.

10. The spindle nut (E) Fig. 8, should then be adjusted so that the distance from the top of the nut to the top of the spindle is $1/4$ to $5/16"$.

11. TO CALIBRATE THE SPINDLE SPEED turn the drill press on and turn pilot wheel clockwise. When the outside circumference of the belt extends $1/32"$ beyond the outside circumference of the motor pulley, turn off the power, loosen locknut (G) Fig. 8, and adjust the stop screw (H) until it is bearing against the bottom of the bearing retainer (J). With a 1725 rpm motor the speed of the drill press will be approximately 4700 rpm. With a 1140 rpm motor the speed of the drill press will be approximately 3100 rpm. Now set the pointer (B) Fig. 2,

to the corresponding speed on the spindle speed chart by unscrewing and removing the pilot wheel hand levers (A) Fig. 2, and loosening the set screws located directly under the hand levers. The hub of the pilot wheel assembly can then be rotated until the pointer points to the corresponding speed on the spindle speed chart (B) Fig. 2. Then tighten the set screws and replace the pilot wheel hand levers (A) Fig. 2.

12. Turn the drill press on and rotate the pilot wheel counterclockwise until the pointer is pointing to the lowest rpm mark on the speed dial and turn off the drill press. Adjust the stop screw (F) Fig. 8, against the roller cam follower on the pilot wheel cam assembly. To adjust stop screw (F) Fig. 8, first loosen locknut (C) Fig. 2.

13. For a more accurate check, use a tachometer to check the spindle speeds.

LUBRICATION

The pulleys should be lubricated weekly in the oil holes located at (K and L) Fig. 8. Oil the holes when the drill press is turned off. Then turn on the drill press and run the machine from low speed to high speed a few times.

The ball bearings in the quill and spindle pulley are grease-scaled for life. The quill is oiled through oiler (H) Fig. 6, which is on the left side of the drill press head. The head has a groove on the inside to allow the oil from the oiler (H) to flow down and oil the pinion shaft and rack.

The spindle return clock spring should be oiled three or four times a year. This is lubricated through the oil holes provided in the clock spring housing (D) Fig. 6.

COMPENSATION FOR BELT AND PULLEY WEAR

After a long period of time pulley and belt wear and stretching of the belt may cause a slight change in the speed of the drill press. To compensate for this change in speed, use a tachometer and move the motor toward or away from the spindle pulley until the correct speed is obtained.

ROCKWELL GUARANTEE

Rockwell is proud of the quality of the power tools which it sells. The component parts of our tools are inspected at various stages of production, and each finished tool is subjected to a final inspection before it is placed in its specially designed carton to await shipment. Because of our confidence in our engineered quality, we agree to repair or replace any part or parts of Rockwell Power Tools or Rockwell Power Tool Accessories which examination proves to be defective in workmanship or material. In order to take advantage of this guarantee, the complete portable power tool or accessory, or in the case of machinery, the part must be returned prepaid to the appropriate factory, factory branch, or authorized service station for our examination. This guarantee, of course, does not include repair or replacement required because of misuse, abuse, or normal wear and tear. Repairs made by other than our factory, factory branch, or authorized service station, relieves Rockwell of further liability under this guarantee. This guarantee is made expressly in place of all other guarantees expressed or implied with respect to fitness, merchantability or quality.

MOTORS

Motors are built to Rockwell's specifications by only leading motor manufacturers. A service station list is supplied with your motor and all defective motors (both in and out of guarantee) should be taken to the local authorized repair station when service is desired.

AUTHORIZED PARTS DISTRIBUTORS

CALIFORNIA

LOS ANGELES, 90007
Rockwell Manufacturing Company
2400 South Grand Avenue
Phone: 213 749-0386

OAKLAND, 94601
Rockwell Manufacturing Company
445 Lesser Street
Phone: 415 535-2424

COLORADO

DENVER, 80207
Rockwell Manufacturing Company
4900 East 39th Avenue
Phone: 303 388-5803

GEORGIA

ATLANTA, 30318
Rockwell Manufacturing Company
1495 Northside Drive N.W.
Phone: 404 351-5434

HAWAII

HONOLULU, 96819
Rockwell Manufacturing Company
3209 Kaapaka Street
Phone: 808 872-048

ILLINOIS

CHICAGO, (Melrose Park), 60160
Rockwell Manufacturing Company
4533 North Avenue
Phone: 312 921-2650

MASSACHUSETTS

BOSTON, (Allston), 02134
Rockwell Manufacturing Company
414 Cambridge Street
Phone: 617 782-1700

MICHIGAN

DETROIT (Southfield), 48075
Rockwell Manufacturing Company
18650 West Eight Mile Road
Phone: 313 358-1000

MISSOURI

KANSAS CITY, 64108
Rockwell Manufacturing Company
1649 Jarboe Street
Phone: 816 221-2070

NEW YORK

NEW YORK, 10013
Rudolf Bass, Incorporated
175 Lafayette Street, Cor. Grand Street
Phone: 212 CA 6-4000

BUFFALO, 14204
Karle Saw Company, Incorporated
138-150 Chicago Street, Cor. So. Park Avenue
Phone: 716 853-8053 or 853-8054

OHIO

CINCINNATI, 45203
Rockwell Manufacturing Company
906 Dalton Street
Phone: 513 241-2737

CLEVELAND, 44114
Rockwell Manufacturing Company
1234 East 26th Street
Phone: 216 621-6329

OREGON

PORTLAND, 97232
Rockwell Manufacturing Company
2755 Northeast Broadway
Phone: 503 288-6888

PENNSYLVANIA

PHILADELPHIA, 19120
Rockwell Manufacturing Company
4433-37 Whitaker Avenue
Phone: 215 455-7907

PITTSBURGH, 15208
Rockwell Manufacturing Company
400 North Lexington Avenue
Phone: 412 241-8400

TEXAS

DALLAS, 75247
Rockwell Manufacturing Company
2934 Iron Ridge Street
Phone: 214 631-1890

WASHINGTON

SEATTLE, 98101
Rockwell Manufacturing Company
1918 Minor Avenue
Phone: 206 622-4576


WISCONSIN

MILWAUKEE, 53222
Rockwell Manufacturing Company
10700 West Burleigh Street
Phone: 414 774-3650

CANADA

GUELPH, ONTARIO
Rockwell Manufacturing Company
of Canada Limited
40 Wellington Street
Post Office Box 848
Phone: 807 822-2840


Authorized Parts Distributors stock a complete line of replacement parts. To save time and shipping cost send your parts orders to your nearest distributor and in most cases they will be filled and shipped within 48 hours. We do not fill any parts orders direct from the factory.



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	
1	402-04-054-5014	Rear Guard	40	901-03-061-2471	5/16 x 3/4 Soc. Hd. Shoulder Screw	
	SP-605	5/16-18 x 1/2 Hex. Hd. Scr.				
	SP-1620	11/32 x 11/16 x 1/16 Washer	**	45	402-04-405-5012	
4	960-03-010-2415	Decal	46	402-04-074-5002	Spindle Assembly, incl.:	
5	402-07-104-5004	Spacer	47	CBS-116	Plug	
6	902-03-050-2974	Speed Nut	48	SP-208	Special Nut	
7	901-06-171-7368	#10-24 x 5/8 Truss Hd. Self- Tapping Screw	49	402-04-063-5001	1/4-20 x 1/4 Hex. Soc. Set Scr.	
8	SP-7008	Retaining Ring	50	901-04-150-9439	Drag Plug	
9	402-04-019-5001	Cam	51	402-04-108-5011	1/4-20 x 1/4 Hex. Soc. Set Scr.	
10	927-01-010-2633	Key	**	52	402-04-099-5001	Rod (3/16 dia. x 3-3/8 lg. Nylon)
11	402-04-106-5010	Shaft	53	402-04-105-5012	Wick	
12	928-06-011-8888	Spring Washer	54	SP-7025	Spindle Sleeve	
13	SP-208	1/4-20 x 1/4 Soc. Set Scr.	55	SP-5360	Retaining Ring	
14	402-04-063-5001	Drag Plug	56	SP-7352	Bearing	
15	SP-607	5/16-18 x 3/4 Hex. Hd. Scr.	57	DP-514	Spring Washer	
16	SP-1620	11/32 x 11/16 x 1/16 Washer	58	SP-317	Retainer	
17	402-04-054-5013	Front Guard	59	SP-5435	5/16-18 x 2 Sq. Hd. Set Scr.	
18	960-01-012-0019	Guard Nameplate	60	SP-5435	5/16-18 Hex. Jam Nut	
19	SP-2250	#4 x 3/16 Drive Screw	61	901-07-251-8538	3-1/4 Stud	
20	402-04-037-5006	Speed Dial	62	901-07-251-8539	2-1/8 Stud	
21	SP-2250	#4 x 3/16 Drive Screw	63	SP-5435	5/16-18 Hex. Jam Nut	
22	928-06-011-8888	Spring Washer	64	240-87	21/64 x 15/16 x 1/8 Washer	
23	402-04-075-5003	Pointer	65	Cat. #41-952	Motor Pulley Assembly (1/2 Bore), incl.:	
24	402-04-072-5008	Instruction Plate	66	SP-7017	Retaining Ring	
25	402-04-107-5001	Hub	67	402-04-020-5001	Cap	
26	SP-1111	3/8-16 x 3/8 Soc. Set Screw	68	928-01-601-8887	Spring	
	402-04-108-5009	Rod	69	402-04-063-5001	Drag Plug	
28	FJ-324	Ball	70	SP-9415	1/4-20 x 1/4 Hex. Soc. Set Scr.	
29	SP-5435	5/16-18 Hex. Jam Nut	71	402-04-108-5010	Rod (3/16 dia. x 4" lg. Nylon)	
30	SP-287	5/16-18 x 1-1/4 Soc. Set Scr.	72	SP-208	1/4-20 x 1/4 Hex. Soc. Set Scr.	
35	901-03-061-2470	5/16 x 3/8 Soc. Hd. Shoulder Screw	73	Cat. #41-953	Motor Pulley Assembly (5/8 Bore), including:	
			74	SP-7017	Retaining Ring	
36	402-04-014-5013	Bracket	75	402-04-020-5001	Cap	
37	SP-4558	5/16-18 x 1-1/4 Headless Set Screw	76	928-01-601-8887	Spring	
38	SP-5435	5/16-18 Hex. Jam Nut	77	402-04-063-5001	Drag Plug	
39	402-04-080-5001	Roller	78	SP-9415	1/4-20 x 1/4 Hex. Soc. Set Scr.	
			79	402-04-108-5010	Rod (3/16 dia. x 4" lg. Nylon)	
			80	SP-208	1/4-20 x 1/4 Hex. Soc. Set Scr.	
			81	Cat. #49-415	Variable Speed Belt	

** When replacing the spindle sleeve or the spindle pulley on machines with serial numbers between 139-3001 and 146-4269, the complete spindle pulley assembly, 402-04-405-5012, must be ordered.



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
80	Cat. #15-838	Spanner Wrench	124	DP-524-R	Stop Collar, including:
81	Cat. #1584	1/8" Hex. Socket Wrench	125	SP-112	#10-32 x 1/2" Headless Set Screw
82	Cat. #194	5/32" Hex. Socket Wrench	126	SP-622	1/4-20 x 2" Hex. Hd. Screw
83	Cat. #1524	Double End Wrench	*	402-04-408-5005	Stop Rod Assy., consisting of:
84	Cat. #1526	Double End Wrench	127	SP-1584	#6-32 x 1/4" Thumb Screw
85	Cat. #1538	Double End Wrench	128	DP-561	Holding Nut
86	402-04-057-5009	Head Casting	129	402-04-088-5005	Micro-Nut
87	SDP-49	Column Clamp	130	402-04-108-5007	Stop Rod
88	SDP-21	Clamp Sleeve	131	DP-221	1/4"-20 Special Nut
89	CBL-447	33/64 x 7/8 x 1/16" Washer	132	SP-1005	3/8-16 Hex. Nut
90	SP-1282	1/2"-13 Hex. Nut	133	Cat. #15-830	Chuck, including:
91	907-01-050-5239	Oiler	134	DP-597	Key
92	928-08-011-8868	Pinion Clock Spring	135	Cat. #15-833	#2 Morse Taper Spindle Adapter
93	DP-528	Clock Spring Housing	136	Cat. #1010	Support Collar, including:
94	902-01-281-7295	1/2"-20 Hex. Lock Nut	137	SP-641	7/16-14 x 3-1/2" Hex. Hd. Scr.
95	DP-675	Ball Crank	138	SP-1004	7/16"-14 Hex. Nut
96	DP-527	Adjusting Screw	139	Cat. #15-804	2-3/4" dia. x 33-3/4" Column (Bench Model)
97	SD-18	1/4"-20 Hex. Nut	139	Cat. #15-805	2-3/4" dia. x 38-3/4" Column (Bench Model)
98	SDP-22	Clamp Sleeve	139	Cat. #15-806	2-3/4" dia. x 65-1/4" Column (Floor Model)
99	SP-621	1/2-13 x 5-1/2" Hex. Hd. Scr.	139	Cat. #15-810	2-3/4" dia. x 78" Column (Floor Model)
100	SP-5435	5/16"-18 Hex. Jam Nut	*	Cat. #15-809	Table Complete, consisting of:
101	SP-378	5/16-18 x 7/8" Sq. Hd. Set Scr.	140	SP-2360	1/2"-13 x 3-1/4" Sq. Hd. Bolt
102	960-02-012-1450	Nameplate	141	402-04-105-5005	Sleeve
103	SP-2250	#4 x 3/16" Drive Screw	142	DP-204-A	Bracket Assy., including:
104	FJ-324	Knob	143	SP-618	1/2-13 x 3-1/2" Hex. Hd. Screw
105	DP-632	Rod	144	DP-560	Scale
*	402-04-407-5004	Hub Assembly, consisting of:	145	SP-2849	#6 x 1/4" Drive Screw
106	402-04-107-5002	Hub	146	DP-205-S	Lock Bolt
107	905-01-010-6745	3/16 x 1-7/8 Roll Pin	147	DP-6	Special Washer
108	402-04-051-5008	Pinion Shaft	148	402-04-001-5004	Table
109	SP-1232	7/16"-20 Hex. Nut	149	SP-1636	17/32 x 1-1/16 x .095" Washer
110	SP-703	1/4-20 x 1-3/4" Fil. Hd. Scr.	150	SP-1028	1/2"-13 Hex. Nut
111	438-01-021-0081	Switch Bracket	151	DP-8	Index Pin
112	SP-3019	#6 x 1/2" Rd. Hd. Self-Tapping Screw	152	402-04-005-5006	Base (Floor Model)
113	DP-572	Switch Opening Cover	153	402-04-027-5003	Column Clamp
114	SP-3015	#6 x 1/4" Rd. Hd. Self-Tapping Screw	154	SD-27	1/2 x 1-1/2 x 1/8 Washer
*	402-04-377-5003	Quill Assembly, consisting of:	155	SP-5437	7/16"-14 Hex. Nut
115	SP-7411	Retaining Ring	156	402-04-005-5008	Base (Bench Model)
116	SP-5384	Bearing	157	402-04-027-5003	Column Clamp
117	NL-306	Bearing Loading Spring	158	SD-27	1/2 x 1-1/2 x 1/8 Washer
118	402-04-077-5002	Quill	159	SP-5437	7/16"-14 Hex. Nut
119	BG-12	Bearing Nut	*	Not shown assembled.	
120	402-04-385-5006	Spindle Assy., including:			
121	SP-7410	Retaining Ring			
122	SP-5384	Bearing			
123	SP-3769	Gasket			



FOR

SERVICE,

and PERFORMANCE in
WOODWORKING and METALWORKING
MACHINES
and
POWER TOOLS